

SL T2™ WIRE MESH FACE SHIELD

ENGINEERED PROTECTION THAT SURROUNDS

The SL T2 Wire Mesh Face Shield is a versatile companion for the SL T2 Safety Helmet, designed to enhance safety and comfort in demanding work environments. Its mesh design ensures optimal air circulation, making it ideal for conditions with smoke and flying debris. Effortlessly attaches to the SL T2 Safety Helmet for added convenience and protection.



FEATURES

Advanced Air Circulation: Wire Mesh design allows for excellent air circulation without compromising protection from potential hazards, making it ideal for use in conditions with smoke and flying debris

Enhanced Safety: Constructed from robust materials, the shield frame and adapter protect and support face shield

User-Friendly Design: Ratchet clips make visor adjustments intuitive and efficient

Effortless Attachment: Attach and detach the face shield with ease, thanks to its quick-release/connect clip design that ensures a snug and secure fit every time

Engineered Toughness: Meets ANSI/ISEA Z87.1-2020 requirements

i HPT2FVM60 sold separately from the SL T2 Safety Helmet. Face Shield offers secondary protection and should be worn with safety eyewear or goggles.



TOOLS AT YOUR FINGERTIPS

Learn more about the SL T2 Helmet and Accessories

SL T2™ WIRE MESH FACE SHIELD

ENGINEERED PROTECTION THAT SURROUNDS

The SL T2 Wire Mesh Face Shield is a versatile companion for the SL T2 Safety Helmet, designed to enhance safety and comfort in demanding work environments. Its mesh design ensures optimal air circulation, making it ideal for conditions with smoke and flying debris. Effortlessly attaches to the SL T2 Safety Helmet for added convenience and protection.

VARIATION

HPT2FVM60



MATERIALS

Screen: Iron Wire Mesh

Frame: ABS (Acrylonitrile Butadiene Styrene) Plastic
--

⚠ WARNING: Cancer and Reproductive Harm –P65Warnings.ca.gov

GENERAL SPECIFICATIONS

Weight: 140g

Overall Length: 227mm

Overall Width: 133mm

MARKINGS

Standard: ANSI/ISEA Z87.1-2020

Product markings may vary // Updated as of 06.24

INSTRUCTIONS

To Attach Clips to Helmet

1. Check for L and R indicators on the backside of each clip.
2. Place the left and right clips in the corresponding front accessory slots of the helmet.

To Attach Face Shield to Clips

1. Position the face shield over the holes on the clips.
2. Press in to ensure a secure fit.

To Remove Face Shield from Clips

1. Press the button labeled "PUSH" at the top of the clip.
2. Pull the shield out of the clip.

To Remove Clips from Helmet

1. Simply pull up on the clips to detach them from accessory slots.

To Remove Face Shield from Adapter

1. Locate the sliders on each side holding the shield to the adapter.
2. Push each slider back to unlock the shield.
3. Turn the face shield over to view the inside and unlock shield from the middle hook.

To Attach Face Shield to Adapter

1. To replace the shield, first attach the middle hook to back of adapter.
2. Align slots on the far edges, and slide sliders back into place.