

# SL T2™ CHIN STRAP

## ENGINEERED PROTECTION THAT SURROUNDS

The SL T2 4-Point Chin Strap is designed to enhance the SL T2 Safety Helmet with improved safety and comfort. This durable strap ensures a secure fit, providing peace of mind in various work environments. Its interchangeable design allows for easy replacement when the strap becomes dirty or sweaty, ensuring continuous protection and comfort for wearers.



## FEATURES

**Hygienic Solution:** Enables wearer to effortlessly replace a dirty or sweaty strap, promoting cleanliness and comfort

**Secure Fit:** The 4-point cross-over design ensures a snug and secure fit for maximum safety

**Comfortable Wear:** Adjustable features ensure comfort throughout the workday

**Durable Construction:** Made from high-quality materials, the chin strap is built to last

## MATERIALS

Webbing: Nylon
O-Ring: Silicone
Webbing Hook and Divider: PS (Polystyrene)
Webbing Tail Clip: PP (Polypropylene)

⚠ WARNING: Cancer and Reproductive Harm –P65Warnings.ca.gov

## GENERAL SPECIFICATIONS

Weight: 43.3g
Adjustable Length: 380-555mm
Width: 15mm

Updated as of 06.24

**i** HPT2RSTRAP is a replacement chin strap sold separately from the SL T2 Safety Helmet.

## INSTRUCTIONS

### To Remove Chin Strap from Helmet

1. Locate the bottom of the tab where the chin strap connects to the helmet.
2. Push and hold the bottom of the tab.
3. Pull strap firmly to detach it from the helmet.
4. Repeat for the other three points.

### To Attach Chin Strap to Helmet

1. Before installing, ensure plastic O-ring is in place on the strap.
2. Align the chin strap to ensure that the closure is positioned at the front of the helmet.
3. Firmly press each of the four tabs on the chin strap into their respective slots on the helmet.
4. Ensure that each tab firmly locks into place for a secure fit.

*A sturdy, flat object can be used to depress the tab.*



## TOOLS AT YOUR FINGERTIPS

Learn more about the SL T2 Helmet and Accessories